


Tack Room Video Conferencing

- Using provided ethernet cable, plug into Polycom TC8 touch screen and into the ethernet port on the wall beneath the North TV
- From the Polycom TC8 Touchscreen's Home Screen, select "Device Mode". (This will allow your laptop to act as the video conferencing interface and the Polycom camera and microphones to provide video and sound to the participants on the video conference)
- Using provided USB cable, plug into laptop's USB-A port and into the USB-A port on the wall beneath the North TV
- Using provided HDMI cable, plug into laptop's HDMI port and into the HDMI port on the wall beneath the North TV
- Once in device mode, launch your preferred video conferencing software (Zoom, Teams, Webex, etc.) on your laptop.
- Within the video conferencing software, select Polycom G7500 video for your camera and Polycom G7500 audio for your mic. (The exact location of these settings will vary depending on which video conferencing software you are using)



- Connection Diagram